

PRODUCT DATA SHEET •

STAAD[®] Advanced Concrete Design

Robust Concrete Design

UP-LEVEL YOUR CONCRETE STRUCTURES

STAAD Advanced Concrete Design takes the design of your concrete structures to the next level. Designed by practicing engineers for practicing engineers, STAAD Advanced Concrete Design adds onto the power of Bentley's STAAD.Pro[®] analytical engine with robust concrete design.

OPTIMIZE YOUR DESIGN

With STAAD Advanced Concrete Design, you can design a variety of concrete elements:

- Columns and walls Rectangular, circular, L, T, C, and other irregular shapes
- Beams Regular and flanged beams
- Foundations Pad footings and pile caps
- Slabs (empirical method)
- Tank walls and tank slabs (FEM analysis)

Take advantage of the design capabilities to:

- Optimize and control design by setting carefully considered parameters
- Manage code compliance and safe design
- Set preferences for maximum and minimum reinforcing ratios, bar sizes, and bar spacing
- Perform optional checks like crack-width during the design process and ensure that your final design satisfies all requirements
- Automate your design process with the highly intuitive algorithm
- Generate practical rebar arrangements that recognize the continuity
 of columns and beams
- Perform manual override and interactive design with powerful, easy-to-use tools
- Enable corrective action using the cause analysis functionality

DESIGN TO INTERNATIONAL STANDARDS

You can extend the reach of your business practice and take advantage of global design opportunities by using a wide range of international standards and specifications. With STAAD Advanced Concrete Design, it is easy to design and produce drawings according to global design standards and in compliance with publications from India (IS), United Kingdom (GB), United States (ACI), and Europe (EC), which can include Malaysia, Singapore, and Belgian National Annexes, Philippines (NSCP), and Australia (AS).

COMPLY WITH SEISMIC REQUIREMENTS

When constructing in seismically active regions, additional provisions might need to be made for the effects of such events. With STAAD Advanced Concrete Design, you can ensure that your designs account for these provisions by generating seismic loads in the analysis according to the relevant building code and include the details for seismic force-resisting systems. You can consider these forces in the design of elements and, where applicable, the design of frames and the larger structural system. Also, you can enforce the ductility requirements of the selected design code in element proportioning and detailing. In case of structural shear wall, the critical checks such as provision of boundary elements are automated.

CREATE COMPREHENSIVE QUANTITY TAKEOFFS

With your designs complete, it is easy to gain critical insight into concrete design alternatives with comprehensive material takeoffs and cost estimation organized by material, size, and shape. Additionally, you can gain a better understanding of the overall construction by obtaining formwork area and cost estimates up front.

PRODUCE CONCRETE DRAWINGS AND SCHEDULES

The main requirement from the design process is the production of project documents. With STAAD Advanced Concrete Design, you can produce comprehensive reinforcing drawings including automated reinforcing labels, dimensions, and notes, as well as reinforcing placing drawings, including sections, plans, and details from the 3D model. You can customize all drawings in terms of colors for various entities and text styles to adhere to your company's standards and automatically update your drawings based on changes to the 3D model.

With the design checks complete, you can quickly produce detailed design drawings for beam line elevations, column line elevations, automatic cross section details, and bar termination geometry. You can create individual beam bar bending schedules, column schedule tables, and beam schedule tables.

SYSTEM REQUIREMENTS

MINIMUM: 1280 x 1024 resolution, 500 MB free space, 2 GB of RAM, Microsoft Windows 8.1 (64-bit) **RECOMMENDED:** 4 GB of RAM, 24-bit high color, Microsoft Windows 10 (64-bit)

STAAD Advanced Concrete Design At-A-Glance

DESIGN

- Automatically determine beam member continuity to provide continuous, practical reinforcement
- Automatically identify columns, walls, and their continuity over the height of the building to ensure continuity of reinforcement
- Produce practical designs by grouping. Identify groups of levels for design of beams or columns. Define groups of multiple elements for most critical design to be adopted for beams, columns, and foundations
- Control automatic designs through simple dialogues
- Control detailing requirements through simple dialogues
- Validate designs with summary graphics, which enable user modifications to prescribe alternative solutions
- Modify the design to suit special requirements using simple tools
- Lock and unlock designs to prevent accidental editing
- Produce detailed calculations. Generate drawings for general arrangements, test schedules, detailed sections, and elevations. Obtain detailed bills of quantity for each entity
- Design columns for standard or more complex shapes
- Determine slab design without having to specify a finite element mesh
- Design foundations like pad, stepped, or pile caps (up to six piles) for RCC and steel structures. For steel structures, design pedestal columns up to the foundation
- Design fluid-retaining structures, analyzed using parametric surface modeling in STAAD. The design of tank walls and slabs is supported for EN base code and other annexes. Identify walls and slabs analyzed with FEM models. Generate section forces for specified width at specified intervals. Produce zonal and curtailed detailing for walls. Manage design using flexural crack-width and drying-shrinkage crack-width

E	1 5-	ð- •					mpleals [C	ompatibility	Mode] - Er	kel				Carlos Agu	era 💷	-	D X
	e B	ome l															A Share
Pas Pas Cip	i X Ib Ioand Is	Century (Sethic • 10 L • 🖽 • Pont	- K /	- = = ↔ 500 - = = = ↔ 500 - Alignment	Vrap Text Aorge & Cento	Gen r	• 96 • Number	- 	onditional A rmatting -	renmat as Table - St tyles	Cel Ins	et Delete	Format	AutoSum Fill • Clear • Ei	Sort & I Filter - S	P ind & islect -
-1				7+ ER	r				12	1. 17				N	0		
1	tiement	Bar	Bar Nes.	Bar Dia.	Bar Shape	Cutting			Dime	nsions				Bar Dia	8	12	Total
2		Mark				Length	A	8	с	D	5	R					
3	Cl	81	6	12		3870	300	1954	73	12	1615	48		LGT (M)	122	74	196
4	CI	82	6	12	A C E	3380	300	1954	73	12	1123	48		WT (KO)	50	66	116
5	CI	83	6	12		2095	300	1264	73	12	492	48					
6	CI	84	6	12	D+ B	2585	300	1786	73	12	492	48					
7	C1	55L	9	8	С А в	1795	400	400									
8	CI	36L	9	8	Г А В	1280	142	400									
	C1	\$7L		8	A 8	1280	400	142									
10	Cl	SBL.	18	8	С А _В	1795	400	400									
	C1	59L	18	8	A B	1280	142	400									
1		885	Sheet1	BAR SHA	PE 🕘	S 2				1 4	1						
Den		and an other states											114	1 10 10	n	1	+ 100%

Produce detailed bar bending schedules.

dvancina Infrastructur

CODES

- ACI 318M-11, ACI 318-11, ACI 318M-14, and ACI 318-14
- IS 456 and IS 13920-2106
- EN 1992 base code national annexes U.K., Malaysia, Singapore, Belgium, and custom
- BS 8110-97
- NSCP 2015
- AS 3600-2018

LOAD MANAGEMENT

- Automatically calculate combinations taking the forces from the analytical model (static and dynamic) and use either the defined combination defined in the analytical model or from a template
- Define cross combinations for irregular buildings
- Use data from STAAD for nonlinear combinations

DELIVERABLES

- Produce drawings in the universal standard DXF format
- Produce general arrangement drawings and reinforcing layouts, plus elevations with cross sections at key locations

INTEROPERABILITY

- Produce reinforcement designs for structural objects to complement the analysis performed in STAAD.Pro and RAM[®] Structural System
- Import STAAD.Pro models with analysis results and filter by floors to design beams, slabs, pad footings, or columns/walls
- Manage the effect of revisions in analysis during column design. Import data from new analysis and check your existing design for revision impacts as well

neu	abgri countri - ci ter un	10 1						10 million (10 mil		
\$	Shape	Size			@D				Ula	
	Set Section	8	500	-	Nos Spacing	4	nn		• •	12
	Rectangle ~	D	500	-					. 1	16 0
	Rebar Arrangement Equi Spaced Zonal			@ B					. Q	
				Nos	2		• •		. 0	
2	Dation Parameter				Specing	128	mm		• 2	8 Q
2	Concrete	M25 ~ Fe415 ~		Edra					2 0	
x	Steel			Nos	Nos 0		the second se	2002	4	
	Cover		50 mm		PT				• 4	10
	Bracing				Ast prov	1709.04				
	Major Auts Minor Auts			Pt Prov	0.684	2		Bars		

Redesign reinforcement quickly and simply.



Produce column capacity graphs.

Bentley[•] FIND OUT MORE AT BENTLEY.COM

1.800.BENTLEY (1.800.236.8539) | Outside the US +1.610.458.5000 | GLOBAL OFFICE LISTINGS bentley.com/contact

© 2023 Bentley Systems, Incorporated. Bentley, the Bentley logo, RAM, RAM Structural System, STAAD, STAAD.Pro, and STAAD Advanced Concrete Design are either registered or unregistered trademarks or service marks of Bentley Systems, Incorporated or one of its direct or indirect wholly owned subsidiaries. Other brands and product names are trademarks of their respective owners. 506205-23